
# ENGINE PART LIST START 88SE




## CYLINDER HEAD ASSY




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 74-06110 | VIS CACHE AAC | BOLT M6×110 | |
| 2 | BT08-M6X20-W | VIS CACHE CULASSE | BOLT M6×20 | |
| 3 | D00L020 | JOINT ALU VIS CACHE AAC | WASHER 6.5×1×12 | |
| 4 | A00A035 | CARTER CULASSE COTE DROIT | RIGHT COVER, CYLINDER HEAD | |
| 5 | 12244/1P52FMI | JOINT CARTER DROIT | GASKET,R.CYLINDER HEAD COVER | |
| 6 | 898-06034 | GOUJON D'ECHAPPEMENT | BOLT M6×32 | |
| 7 | 34210/D8EA | BOUGIE D8EA | SPARK PLUG D8EA | |
| 8 | 1122B-F009-00000W | CULASSE NUE | CYLINDER HEAD ASSY | |


| | | | | |
|---|---|---|---|---|
| 9 | 12246/152FMI | JOINT TORIQUE CACHE SOUPAPE | O-RING 29.6×3.2 | |
| 10 | D00A032PW | BOUCHON CACHE SOUPAPES | COVER, VALVE CHAMBER | |
| 11 | 12242/1P47FMF | CARTER CACHE AAC | LEFT COVER, CYLINDER HEAD | |
| 12 | D00B006 | JOINT CARTER AAC | GASKET,L,CYLINDER HEAD COVER | |
| 13 | W-G20-01002-00 | JOINT COUVRE CULASSE | GASKET, CYLINDER HEAD UPPER COVER | |
| 14 | W-D10-01001 | COUVRE CULASSE | UPPER COVER, CYLINDER HEAD | |
| 15 | D00L012 | RONDELLE CUIVRE | WASHER 6.2×2×13 | |
| 16 | D00L017 | RONDELLE ACIER | WASHER 6.2×2×13 | |
| 17 | 91201-H021-00000X | ECROU CULASSE | NUT M6 | |
| 18 | 17322 | JOINT PIPE | GASKET, INLET PIPE | |
| 19 | BT08-M6X20-W | VIS M6X20 | BOLT M6×20 | |
| 20 | 17311 | PIPE ADMISSION | INLET PIPE | |
| 22 | 17331/152FMH | CALE ADMISSION | GASKET, CARBURETOR | |
| 23 | PZ18FL-SP | CARBURATEUR | CARBURETOR NIBBI PZ 18 | |
| 24 | 18291/152FMH | JOINT ECHAPPEMENT | exhaust gasket | |

## CYLINDER ASSEMBLY





| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 15441/152FMH | PION DE CENTRAGE POUR PASSAGE DE L'HUILE | BUSH 9.5 | |
| 2 | D001L032 | JOINT TORIQUE PASSAGE HUILE CYLINDRE CULASSE | RECTANGLE RING 8×10.8×1.5 | |
| 3 | 12218/152FMI | PION CENTRAGE DE CULLASSE 8x14 | PIN 8×14×6.3 | |
| 4 | 12134/152FMH | JOINT TORIQUE | RECTANGLE RING 11.5×16×2.5 | |
| 5 | 12220F | JOINT DE CULASSE | GASKET ASSY,CYLINDER HEAD | |
| 6 | BT08-M6X16-W | VIS M6X16 MM | BOLT M6×16 | |
| 8 | 29.2-06023 | VIS DE CULASSE | BOLT M6×23 | |
| 9 | C0015A038 | CYLINDRE 88cc 47 mm | CYLINDER BLOCK ASSEMBLY | |
| 10 | 29.2-06030 | VIS DE CYLINDRE | BOLT M6×30 | |
| 11 | 14610/152FMH | ROULETTE DE CHAINE | GUIDE CHAIN ROLLER SET | |
| 12 | W-ZFQ5286D8-01 | RONDEL JOINT ROULETTE DE CHAINE | WASHER 8×1.5×14 | |
| 13 | 14621/152FMI | VIS DE ROULETTE DE CHAINE | GUIDE CHAIN ROLLER PIN | |
| 14 | 12134/152FMH | JOINT TORIQUE pied de cylindre | RECTANGLE RING 11.5×16×2.5 | |
| 15 | 12121F | JOINT EMBASE | GASKET,CYLINDER BLOCK | |
| 16 | 11318/152FMI | PION DE CENTRAGE CYLINDRE | PIN 8×12×6.3 | |

## GASKET




| | | | | |
|---|---|---|---|---|
| 1 | PJCMSE | POCHETTE DE JOINTS COMPLETE 125/88SE | COMPLETE ENGINE GASKET KIT | |
| 2 | PJHM88 | POCHETTE DE JOINTS HAUT MOTEUR | HIGH ENGINE GASKET | |


## VALVE MECHANISM




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 14752/152FMH | DEMI LUNE | VALVE COTTER | |
| 2 | 15705-D002-0000 | COUPELLE SOUPAPES | SPRING SEAT | |
| 3 | 15704-D002-0200 | RESSORT INTERIEUR | VALVE INNER SPRING | |
| 4 | 15703-D002-0000 | RESSORT EXTERIEUR | VALVE OUTER SPRING | |
| 5 | 15710-D002-0200 | JEU DE RESSORTS | INNER SPRING,ASSY | |
| 6 | 14730/152FMH | JOINT QUEUE DE SOUPAPE | SEAL, VALVE STEM | |
| 7 | D00F045 | SOUPAPE ADMISSION 88cc 23x5x66mm | INLET VALVE 88cc 23x5x66mm | |
| 8 | D00F039 | SOUPAPE D'ECHAPPEMENT 88cc 20x65x5mm | EXHAUST VALVE | |
| 10 | 14416/152FMH | ECROU DE REGLAGE DE LINGUET DE SOUPAPE | NUT,VALVE CLEARANCE | |
| 11 | 14415/152FMH | VIS DE REGLAGE DE LINGUET DE SOUPAPE | SCREW, VALVE CLEARANCE | |
| 12 | 14410/152FMI | BASCULEUR DE SOUPAPE | ROCKER ARM ASSEMBLY, VALVE | |
| 13 | 14413/152FMH | AXE DE BASCULEUR | ROCKER SHAFT | |
| 14 | 14100/139FMB | ARBRE A CAMES | GAMP SHAFT COMP | |
| 15 | A00F011 | POULIE ARBRE A CAMES | TIMING DRIVEN SPROCKET | |
| 16 | 5783-05012 | VIS M5X12 | BOLT M5×12 | |
| 17 | 14670/152FMH | BASCULEUR TENDEUR | CHAIN ADJUSTING SET | |
| 18 | 14661/152FMH | VIS BASCULEUR TENDEUR | AXLE, TENSIONER LEVER | |


| | | | | |
|---|---|---|---|---|
| 19 | 14530/152FMH | TENDEUR DE CHAINE | CHAIN TYHT SET | |
| 20 | 14680/152FMH | ROULETTE DE CHAINE | LIFTER ASSY | |
| 21 | 14513/152FMH | RESSORT TENDEUR | SPRING | |
| 22 | 14519/152FMH | JOINT BONCHON TENDEUR | WASHER 14×1.5×20 | |
| 23 | 14518/152FMH | BOUCHON TENDEUR | SEALING PLUG M14×1.5 | |
| 24 | D00F012 | CHAINE DISTRIBUTION | SPROKET CHAIN | |
| 25 | 15706-D002-0000 | RONDELLE SOUS RESSORT | OUTER VALVE SPRING RETAINER | |

## RIGHT CRANKCASE COVER





| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 15611/152FMH | JAUGE A HUILE 131,5 MM | OIL RULER ASSY | |
| 2 | D00C060 | JOINT JAUGE | O-RING 18×3 | |
| 3 | 2244A-G031-00000X | BUTE EMBRAYAGE | CLUTCH TAPPET | |
| 4 | 22440-G011-0000 | TRIPOD BUTE EMBRAYAGE | CLUTCH TAPPET | |
| 5 | 91112-G031-00000X | POUSSOIR EMBRAYAGE | BOLT M8 | |
| 6 | 11318/152FMI | PION DE CENTRAGE 8×12×6.3 | PIN 8×12×6.3 | |
| 7 | E041B002 | JOINT CARTER EMBRAYAGE | GASKET, R.CRANKCASE COVER | |
| 8 | 11310/1P52FMK | CARTER EMBRAYAGE | COVER COMP. RIGHT CRANKCASE | |
| 9 | 74-06080 | VIS M6X80 | BOLT M6×80 | |
| 10 | 74-06090 | VIS M6X90 | BOLT M6×90 | |
| 11 | 74-06065 | VIS M6X65 | BOLT M6×65 | |
| 12 | RCSC-BK | DEMI CARTER EMBRAYAGE NOIR | DECORATE COVER,R.CRANKCASE COVER | |
| 13 | B008200006001620X | VIS M6X16 | SCREW M6×16 | |
| 14 | B061700008000060B | ECROU | NUT M8 | |
| 15 | B0009701080000M0B | RONDELLE | WASHER ϕ8 | |
| 16 | 90101-10080000180 | JOINT TORIQUE | O-RING 8×1.8 | |
| 17 | 74-06040 | VIS M6X40 | BOLT M6×40 | |
| 18 | 27190/152FMH | JOINT SPI DE KICK | OIL SEAL 13.8×24×5 | |
| 19 | 74-06040 | VIS M6X40 | BOLT M6×40 | |

## LEFT CRANKCASE COVER




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 12303-G011-000089 | BOUCHON PMH | CAP, SMALL VIEW HOLE | |
| 2 | 90101-10132000265 | JOINT TORIQUE | O-RING 13.2×2.65 | |
| 3 | 11318/152FMI | PION DE CENTRAGE | PIN 8×12×6.3 | |
| 4 | 90204-D083-0000 | JOINT DE CARTER ALLUMAGE | GASKET，L.CRANKCASE COVER | |
| 5 | 12301-D083-000189 | CARTER ALLUMAGE | FRONT PART，L.CRANKCASE COVER | |
| 6 | 12302-D083-000089 | CARTER PIGNON SORTIE DE BOITE | BACK PART，L.CRANKCASE COVER | |
| 7 | 74-06025 | VIS M6X25 | BOLT M6×25 | |
| 8 | 74-06055 | VIS M6 X55 | BOLT M6×55 | |
| 9 | 74-06035 | VIS M6X35 | BOLT M6×35 | |
| 10 | 90101-10274000265 | JOINT TORIQUE | O-RING 27.4×2.65 | |
| 11 | 12304-G011-000089 | BOUCHON ALU CARTER ALLUMAGE | CAP, BIG VIEW HOLE | |


**CLUTCH ASSY**




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|


| | | | | |
|---|---|---|---|---|
| 1 | 21100L | EMBRAYAGE SEMI AUTO | CLUTCH ASSY | |
| 20 | 276-6000 | ROULEMENT | BEARING (6000) | |
| 21 | 81905010 | VIS M5X12 | SCREW M5×12 | |
| 22 | 22121-G031-0000 | PLAQUE DE BUTEE EMBRAYAGE | END COVER,CLUTCH | |
| 23 | 22631/152FMH | ECROU CRANTE CLOCHE EMBRAYAGE | LOCK NUT, CLUTCH | |
| 24 | 22632/152FMH | RONDELLE FREIN EPURATEUR ET EMBRAYAGE | DISH WASHER, CLUTCH | |
| 25 | A00G022 | RONDELLE DE BLOGAGE D´EMBRAYAGE A ERGOT | STOP WASHER, CLUTCH | |
| 26 | 23226-D002-0000 | CLIPS | CIRCLIP | |
| 27 | 22610L | COURONNE D'EMBRAYAGE 88cc/125cc SEMI AUTO | DRIVEN GEAR COMP | |
| 28 | 23110-G031-0000 | ENSEMBLE PIGNON BAGUE | DRIVEN GEAR | |
| 29 | E00J019 | BAGUE | AXLE SLEEVE | |
| 30 | 22621/152FMH | PIGNON | PRIMARY DRIVE GEAR | |

## OIL PUMP





| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | W-D10-18017 | POULIE POMPE A HUILE | HUB DUMP CHAIN SPROCKET, OIL PUMP | |
| 2 | 14302-D002-0000 | AXE POMPE A HUILE | OIL PUMP SPROCKET SHAFT | |
| 3 | 14304-D002-0000 | GUIDE | BUSH, SPROCKET | |
| 4 | 90210-D002-0000 | PLAQUE | GASKET,OIL PUMP | |
| 12 | 96006020 | VIS M6X22 | SCREW M6×22 | |
| 13 | 818-06015Z | VIS M6X16 | SCREW M6×16 | |
| 14 | 15100L | POMPE A HUILE COMPLETE | OIL PUMP ASSY | |
| 15 | 15450/152FMH | CREPINE | STRAINER,OIL FILTER | |

## LEFT CRANKCASE





| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | C00M001 | GOUJON A | CYLINDER STUD BOLT A | |
| 2 | 92102-000NK142212 | ROULEMENT | BEARING (NK14×22×12) | |
| 3 | 276-6203 | ROULEMENT | BEARING (6203) | |
| 4 | 20152/152FMH | RENIFLARD | PIPE ASSY | |
| 5 | 97010014 | GUIDE 10X14 | PIN 10×14 | |
| 6 | 74-06060 | VIS M6X60 | BOLT M6×60 | |
| 8 | 74-06050 | VIS M6X45 | BOLT M6×45 | |
| 9 | 23790/152FMH | SPI PSB 17×29×5 | OIL SEAL 17×29×5 | |
| 10 | 74-06065 | VIS M6X65 | BOLT M6×65 | |
| 11 | 24190/152FMH | SPI SELECTEUR 11.6×24×10 | OIL-SEAL 11.6×24×10 | |
| 12 | 90101-10080000180 | JOINT TORIQUE | O-RING 8×1.8 | |
| 13 | 11318/152FMI | SPI SELECTEUR 8×12×6.3 | PIN 8×12×6.3 | |
| 14 | 1212B-D083-000089 | CARTER MOTEUR GAUCHE | LEFT CRANKCASE BLOCK | |
| **RIGHT CRANKCASE** | | | | |




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 92102-0NK13.52212 | ROULEMENT AIGUILLES | NEEDLE BEARING(NK13.5×22×12) | |
| 2 | 276-6203 | ROULEMENT | BEARING (6203) | |
| 3 | 11119/152FMH | JOINT CARTER | GASKET,CRANKCASE | |
| 4 | 11110L | CARTER DROIT | RIGHT CRANKCASE BLOCK | |
| 5 | C00M002 | GOUJON B | CYLINDER STUD BOLT B | |
| 6 | 11213/152FMI | JOINT BOUCHON VIDANGE | WASHER 12.1×2×20 | |
| 7 | 11212/152FMI | BOUCHON VIDANGE | OIL DRAIN PLUG | |


## CRANKSHAFT CONNECTING-ROD ASSY/PISTON




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 13300F | SEGMENTS Ø 46,5mm 88cc | PISTON RING COMP | |
| 2 | KPC/47-13SE | KIT PISTON COMPLET | COMPLETE PISTON KIT | |
| 5 | 13222/152FMI | CLIPS PISTON 13MM | CHECK RING, PISTON PIN | |
| 7 | 13221/152FMH | AXE DE ÏSTON 13MM | PIN PISTON | |


| | | | | |
|---|---|---|---|---|
| 10 | 13118/152FMH | CLAVETTE | SEMICIRCULAR KEY | |
| 12 | 13100/1P47FMF | VILEBREQUIN 88 AXE DE PISTON 13 | CRANKSHAFT CONNECTING-ROD ASSY | |

## TRANSMISSION MAIN,COUNTER SHAFT




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 23220-D002-0000 | ARBRE PRIMAIRE DE BOITE 88/125 SE | MAIN SHAFT, TRANSMISSION | |
| 9 | 23240-D002-0000 | ARBRE BOITE SECONDAIRE 88/125 SE | COUTERSHAFT TRANSMISSION | |
| 20 | 22711/152FMZ15 | PSB 15 dts | DRIVE SPROCKET 15 teeths | |
| 21 | 22712/152FMH | PLAQUE DE PIGNON Ø 17 | FIXING PLATE,DRIVE SPROCKET | |
| 22 | 5783-06008 | VIS PLAQUE DE PIGNON | BOLT M6×10 | |


## KICK STARTING SHAFT ASSEMBLY




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|


| | | | | |
|---|---|---|---|---|
| 1 | 27100L | ARBRE DE KICK COMPLET | KICK STARTING SHAFT ASSEMBLY | |
| 13 | 5783/06020 | VIS M6X20 | BOLT M6×20 | |
| 14 | 27131/152FMH | PLAQUE BUTEE DE KICK | SPACE, RATCHET WHEEL | |
| 15 | 43451/152FMH | KICK ACIER ORIGINE Ø 13mm | START-UP BAR COMP | |

## GEARSHIFT MECHANISM




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 24300-G030-0000 | ARBRE DE SELECTEUR ZONGSHEN SEMI AUTO 88/125 SE | GEARSHIFT LEVER COMP | |
| 6 | 2242A-G031-0000 | Bras de commande d'embrayage semi auto | CONTROLLING ARM ASSEMBLY, CLUTCH | |
| 7 | 2245A-G031-0000 | Plaque de came d'embrayage semi auto | CAM PLATE ASSEMBLY, CLUTCH | |
| 8 | A004K060 | BARILLET COMPLET | GEARSHIFT DRUM COMP | |
| 9 | FBR | FOURCHETTE DE BOITE | GEARSHIFT FORK | |
| 16 | 24131/152FMH | AXE BUTEE DE SELECTEUR | BOLT, RETURN SPRINGN FIXING 8×11 | |
| 17 | 91115-D002-0000 | VIS LOKER BARILLET | BOLT FIXING PLATE | |
| 18 | 2434A-D002-0000 | ROULETTE BARILLET | LOCATING PLATE ASSY | |
| 19 | 24304-D002-0000 | RESSORT | SPRING ,LOCATING PLATE | |
| 20 | 818-06015Z | VIS M6X15 | SCREW M6×15 | |
| 21 | 35721/152FMH | PATTE | GEARSHIFT SWITCH PRESSING PLATE | |
| 22 | 8803B-G011-010034 | BOUCHON POINT MORT | GEARSHIFT SWITCH LAMP | |
| 23 | 818-06015Z | VIS | SCREW | |
| 24 | 35710/152FMH | RONDELLE CONTACT | CONTACT, CEARINDICATION | |
| 25 | 24700/152FMH/03 | SELECTEUR ACIER REPLIABLE | GEARSHIFT SHAFT | |


## MAGNETO COMP




磁电机总成

| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 82130-G011-0211 | ROTOR SE AVEC ROUE LIBRE DE DEMARREUR | ROTOR ASSY,MAGNETO | |
| 9 | YC110-2011-02 | STATOR ALLUMAGE | STATOR ASSY,MAGNETO | |
| 10 | 31311/152FMH | ECROU ALLUMAGE | NUT | |
| 11 | BT08-M6X20-W | VIS M6X20 | BOLT M6×20 | |
| 12 | GB818-M5X12-W | VIS M5 X12 | BOLT M5×12 | |
| 13 | 12305-D083-0000 | PLAQUE FIXATION | FIXING PLATE, MAGNETO CABLE | |
| 14 | 818-06015Z | VIS M6X16 | BOLT M6×16 | |


**ELECTRIC STARTING MECHANISM**




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | 74-06035 | VIS M6X35 | BOLT M6×35 | |
| 2 | 82200-D083-000151 | DEMARREUR COMPLET | STARTING MOTOR ASSY | |
| 6 | 2144B-D083-0000 | PATIN CHAINE | ASSEMBLY, GUIDE PLATE | |
| 7 | 2143B-D083-0000 | PATIN CHAINE | ASSEMBLY, CHAIN PROTECT PLATE | |
| 8 | 2141B-IA29-0000 | CHAINE DEMARREUR | STARTING MOTOR DRIVE CHAIN | |
| 9 | 21407-G011-0000 | PLAQUE | PLATE, START CLUTCH | |

| | | | | |
|---|---|---|---|---|
| 10 | B057830006001220X | VIS M6X12 | BOLT M6×12 | |
| 11 | 21420-D083-0000 | POULIE DE DEMARREUR 88/125CC | PLATE GEAR ASSY | |
| 14 | 74-061105 | VIS M6X105 | BOLT M6×105 | |
| 15 | D00L020 | RONDELLE | WASHER 6.2×1.5×13 | |
| 16 | 74-06035 | VIS M6X35 | BOLT M6×35 | |
| 17 | D00C019 | JOINT SPI | OIL SEAL 30×42×4.5 | |
| 18 | 74-06025 | VIS M6X25 | BOLT M6×25 | |
| 19 | 12327-D083-00000X | PLAQUE | SUPPORTING CLIP | |
| 20 | 21408-D083-000089 | DEMI CARTER DEMARREUR 88/125 SE | LOWER PAN, OIL INSULATING | |
| 21 | 31915/152FMH | JOINT TORIQUE (GRAND) PLATEAU ALLUMAGE | O-RING 106.8×2 | |

## ELECTRIC




| NO. | (PART CODE) | DESCRIPTION | (ENGLISH DESCRIPTION) | |
|---|---|---|---|---|
| 1 | YC110-1504 | BOBINE HT | IGNITION COIL | |
| 2 | YC110-1503 | C.D.I | C.D.I | |
| 3 | YC110-1502-01 | REGULATEUR | RECTIFIER | |
| 4 | YC50-1510 | RELAIS DEMARREUR | RELAY | |